

# Headset Installation

# Helmet Fitting Guide

## BMW System 4 Helmet

Remove the neckroll by pulling the back of the collar into the helmet and slide both wire guides out from their retaining locators. Detach velcroed flaps (Marked 'A' to right) to expose the polystyrene ear cups.

Thread boom (microphone first) under the chin strap but over the opened velcroed flaps (A).

Locate speakers just below the ear indents under the velcroed flaps (B).

Neatly tuck speaker cable under lining around the back of the helmet and below the neck collar retaining groove, out of sight (C).

Position headset down lead along the outer edge of the helmet under the velcroed flap. This may require additional velcro. Re-attach velcro.

Push the thin section of boom into the joint between the skull and cheek lining and under the chin strap. Locate the boom across the top of left hand cheek pad forming it to follow it's contours. Hold boom down firmly and secure in place with velcro or a suitable sticky backed material (D).

Form the microphone boom so that microphone is situated in-front of and just touching the center of the mouth.

Check that down lead and boom are well secured and wires are neatly tucked away. CAREFULLY check the opening and closing of the front of the helmet to be sure that it does not snag on the boom or down lead.

Test the headset. Adjust mic and speakers as required. Re-fit neckroll.

[Due to the design of this helmet, positioning the speakers directly over the ear canals may not be possible. In this case, one can expect sound quality and volume to diminish when using earplugs.]

