



1



Remove the cheek pad on the side you wish to install the microphone by gently pulling the pad into the helmet until the snaps come undone.

We usually mount the microphone on the left side.

2



Carefully place the mic between the (hard) eps lining and outer shell by wedging the rear of the microphone boom behind the eps liner. Make sure the red mic plug is accessible until it is connected to the rest of the headset.

3



Using a small piece of hook and loop secure the mic boom in place to the outer shell.

4



Pull the lining clip out from between the shell and padding. Run the short speaker wire (mic side) into the channel where the padding and liner meet.

5



Using a small piece of hook and loop secure the speaker in the recess above the chin strap such that the speaker wire is exiting the speaker directly backwards and the point of the speaker carrier opposite the wire is snug against the chin strap.

6



Pull the excess wire to the back of the helmet and using a blunt instrument, push the wire between the outer shell and eps liner while running the long speaker wire to the opposite side of the helmet.

7



Using a small piece of hook and loop, place the second speaker into the other recess as per the instructions in #5. Tuck away any excess wire between the padding and the outer shell.