



1



The cheek pads on the Justissimo are installed with inset snaps.

Un-snap these and remove the cheek pads.

2



Above where the cheek pads were, lift the black lining to expose a recess (speaker positioning area).

3



For some people the recess in the polystyrene is not deep enough, so you may need to compress the polystyrene a few more millimeters deeper. Once this is done place a small amount of velcro in the recess area.

4



Flip the speaker so that the wire on the back of the speaker exits from the top. The speaker is then placed on the velcro in a vertical position. It is advised that the speaker is placed half in the recess area and half out.

5



The microphone boom needs to be placed between the two press studs as pictured. Velcro the microphone boom to the inner shell.

6



To fit the loom joint it is best to use a blunt thin instrument to separate the inner polystyrene shell from the outer shell. About 3cms behind the metal chin strap connector, push the instrument up between the inner polystyrene and the outer shell. Once this is done it is possible to push the loom joint up into the helmet. When the blunt instrument is removed the joint will be pressure fitted between the polystyrene and the outer shell.

7



Once all this has been done, you are ready to put the helmet back together. Clip all the relevant clips together. The longer black wire with the white clip goes around the back of the helmet tucked away to the right hand speaker. Once the cheek pads are in position, make sure that the cheek pads are able to be re-press studded back together.