


Kenwood AT2/AT4 Programmed Frequency and Quiet Talk

Programmed Exclusively for		
		
Channel Number	Frequency (MHz)	Quiet Talk Setting
1	462.5625	Off
2	462.5875	Off
3	462.6125	Off
4	462.6375	Off
5	462.6625	Off
6	462.6875	Off
7	462.7125	Off
8	462.5750 (White)	Off
9	462.6250 (Black)	Off
10	462.6750 (Orange)*	Off
11	462.5500	Off
12	462.6000	Off
13	462.6500	Off
14	462.7000	Off
15	462.7250	Off
16**	462.7625	Off

*Emergency Channel: Use the emergency channel only for the purpose of soliciting or rendering assistance to a traveler, or for communicating in an emergency pertaining to the immediate safety life or the immediate protection of property. This channel is used by certain organizations during emergency situations, and may not be necessarily monitored.

**AT4 Only