

To interface Garmin 2820 to All Systems

(Super Pro Avi, Active-PLUS, Easi-PLUS, Pro-7-Sport, Active-7-Smart, Easi-7-Advance)


For GPS and Music



Utilizing Interface #1314

Enable GPS and Music connection.

1. Insert 3.5mm stereo jack plug into the 3.5mm audio out socket on the side of the 2820.



Interface #1314 is designed to be used with all Autocom Systems. Interface to Systems as follows:

Super Pro AVi — Insert 3.5mm 3-Pole stereo plug into Socket **AUX2**.

Active-PLUS — Insert 3.5mm 3-Pole stereo plug into Socket **AUX2**.

Easi-PLUS — Insert 3.5mm 3-Pole stereo plug into Socket **AUX2**.

Pro-7-Sport/Active-7-Smart/Easi-7-Advance — Insert 3.5mm 3-Pole stereo plug into Socket marked **MUSIC**.

HELPFUL TIPS:

- This configuration will allow the rider to monitor the cell phone as well but they will not be able to reply as the mic line is not connected.
- The Audio Out Socket is located on the side of the zumo's cradle underneath a protective rubber cover.



For GPS and Music plus Cellular Phone



Utilizing Interface #1298

Enables cellular phone, GPS and Music connection.

1. Insert 2.5mm mono plug with the **RED** band into the 2.5mm microphone socket on the 2820.
2. Insert the other 2.5mm stereo plug into the 2.5mm audio out socket that is integrated into the Garmin Motorcycle Power/Audio Lead (Garmin #010-10495-02).



Interface #1298 is designed to be connected as follows:

Super Pro AVi — Insert 3.5mm 4-Pole stereo plug into Socket **AUX1** or **AUX4**.

Active-PLUS — Insert 3.5mm 4-Pole stereo plug into Socket **AUX1** or **AUX3**.

Easi-PLUS — Insert 3.5mm 4-Pole stereo plug into Socket **AUX1** or **AUX3**.

Pro-7-Sport — Insert 3.5mm 4-Pole stereo plug into Socket marked **AUX2**.

Active-7-Smart — Insert 3.5mm 4-Pole stereo plug into Socket marked **Phone**.

Easi-7-Advance — Insert 3.5mm 4-Pole stereo plug into Socket marked **Auxiliary**.

HELPFUL TIPS:

- To connect your phone you must pair your Bluetooth phone to the 2820.
- The Microphone Socket is located on the side of the 2820 underneath the protective rubber cover.
- The Audio Out socket is located on the optional Motorcycle Power/Audio Lead.
- **Do not attempt to use the 3.5mm Audio Out Socket on the 2820 above the microphone socket in this configuration!**

